

SERVICE INTERVALS

Perform at every indicated month or operating hours intervals, whichever comes first

ITEM	ACTION	BEFORE EACH USE	FIRST MONTH OR 5 HOURS	EVERY 3 MONTHS OR 50 HOURS	EVERY 6 MONTHS OR 100 HOURS
Engine Oil	<i>Check Level</i>	◆			
	<i>Change</i>		◆		◆
Air Cleaner	<i>Check</i>	◆			
	<i>Clean</i>			◆	
Fuel tap sediment cup	<i>Clean</i>				◆
Spark plug	<i>Clean - readjust</i>				◆
Valve clearance	<i>Check - readjust</i>				◆
Spark arrestor	<i>Clean</i>				◆
Fuel tank & filter	<i>Clean</i>				◆
Fuel Line	<i>Replace if necessary</i>		Every 3 Years		